

INTAKE-AIR SYSTEM [L3 WITH TC]

WASTEGATE CONTROL SOLENOID VALVE FUNCTION [L3 WITH TC]

E6U011313240S03

- Performs duty control on the pressure applied to the wastegate actuator.

WASTEGATE CONTROL SOLENOID VALVE CONSTRUCTION/OPERATION [L3 WITH TC]


E6U011313240S04

Construction

- Mainly composed of the solenoid coil, spring, and plunger.

Operation

- During energization, the valve opens and performs linear adjustment of the pressure applied to the wastegate actuator releasing it through the air hose.



D6U113ZSC012