

**DTC table [L3 With TC]**

<b>DTC</b>	<b>Malfunction location</b>	<b>DTC output module</b>
U0073	CAN system communication error	<ul style="list-style-type: none"><li>• PCM</li><li>• DSC HU/CM</li><li>• AWD control module</li><li>• Keyless control module</li></ul>
U0100	Communication error to PCM	<ul style="list-style-type: none"><li>• DSC HU/CM</li><li>• AWD control module</li><li>• Keyless control module</li></ul>
U0114	Communication error to AWD control module	DSC HU/CM
U0121	Communication error to DSC HU/CM	<ul style="list-style-type: none"><li>• PCM</li><li>• AWD control module</li></ul>
U0155	Communication error to instrument cluster	<ul style="list-style-type: none"><li>• PCM</li><li>• DSC HU/CM</li></ul>
U0323	Communication error to instrument cluster	Keyless control module
U1900	Communication error to other modules	Instrument cluster
U2023	Abnormal message from PCM	Keyless control module
U2511	Abnormal message from AWD control module	DSC HU/CM
U2516	CAN system communication error	Instrument cluster